


6.5 Alarm Types



7. Specifications

Device Type	Temperature Controller
Housing & Mounting	76mm x 34.5mm x 71mm plastic housing for panel
Protection Class	Mounting. Panel cut-out is 71x29mm. NE MA 4X (Ip65 at front, Ip20 at rear).
Weight	Approximately 0.20 Kg.
Environmental Ratings	Standard, indoor at an altitude of less than 2000 meters with none condensing humidity.
Storage / Operating Temperature	-30 °C to +80 °C / -20 °C to +70 °C
Storage / Operating Humidity	90 % max. (None condensing)
Installation	Fixed installation
Overvoltage Category	II.
Pollution Degree	II, office or workplace, none conductive pollution
Operating Conditions	Continuous
Supply Voltage and Power	115V~ (±15%) 50/60Hz- 1.5VA
Temperature Sensor Input	NTC Thermister (mL-DTC100) PTC Thermister (mL-DTC150)
NTC input type	NTC (10 kΩ@25 °C)
PTC input type	PTC (1000 kΩ@25 °C)
Accuracy	± 1 % of full scale
Sensor Break Protection	Upscale
Sampling Cycle	3 samples per second
Control Form	PIO or ON / OFF
Relay Output	8 A@250 VAC for Resistive load (Compressor Output)(Electrical life100.000 switching at full load)
Display	14 mm Red 4 digits LED Display
Internal Buzzer	>83dB
Approvals	EAC, CE

mL-DTC Series 77x35 DIN Size Digital Temperature Controller



mL-DTC100 & mL-DTC150 Digital Temperature Controllers

- 4 Digits Display
- mL-DT100: NTC Input (-50 to 100°C scale)
- mL-DT150: PTC Input (-50 to 150°C scale)
- Adjustable temperature offset
- PIO or ON/OFF temperature control
- Selectable heating or cooling function
- Selection of operation with hysteresis
- Set value low limit and set value high limit boundaries
- Operation selection of compressor operates continuously, stops or operates periodically in case of sensor defect
- Compressor protection delays
- Alarm parameters
- Adjustable internal buzzer according to sensor defect status.
- Password protection for programming section
- CE compliant according to European Norms

1. Preface


mL-DTC series temperature controllers are designed for measuring and controlling temperature. They can be used in many applications with their compact form, heating and cooling control form and easy-use properties. Some application fields which they are used are below:

Application Fields	Applications
Glass	Heating
Food	Baking Ovens
Plastic	Incubators
Petro-Chemistry	Storages
Textile,	Automotive Air Conditioning
Machine Production Industries Etc...	Etc...

1.1 Environmental Ratings

- Operating Temperature : -20 to 70 °C
- Max. Operating Humidity : 90% Rh (non-condensing)
- Altitude : Up to 2000 m.
- Forbidden Conditions:
 - Corrosive atmosphere
 - Explosive atmosphere
 - Home applications (The unit is only for industrial applications)

1.2 General Specifications



8. Ordering Information

Model Number	Description
mL-DTC100	Digital Temperature Controller 115 VAC (±15%) 50/60Hz - 1.5VA NTC Thermistor Input Type with -50 to 100°C (-58 to 212°F) Scale 1 Form A Relay Control Output (8A@250VAC with Resistive Load) (1 NO) 1 Form A Relay Alarm Output (5A@250VAC with Resistive Load) (1 NO)
mL-DTC150	Digital Temperature Controller 115 VAC (±15%) 50/60Hz - 1.5VA PTC Thermistor Input Type with -50 to 150°C (-58 to 302°F) Scale 1 Form A Relay Control Output (8A@250VAC with Resistive Load) (1 NO) 1 Form A Relay Alarm Output (5A@250VAC with Resistive Load) (1 NO)

NOTES

1.3 Installation

A visual inspection of this product for possible damage occurred during shipment is recommended before installation. It is your responsibility to ensure that qualified mechanical and electrical technicians install this product.

If there is danger of serious accident resulting from a failure or defect in this unit, power off the system and the electrical connection of the device from the system.

The unit is normally supplied without a power switch or a fuse. Use power switch and fuse as required.

Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.

Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.

Never attempt to disassemble, modify or repair this unit. Tampering with the unit may result in malfunction, electric shock or fire.

Do not use the unit in combustible or explosive gaseous atmospheres. During the equipment is put in hole on the metal panel while mechanical installation some metal burrs can cause injury on hands, you must be careful. Mounting of the product on a system must be done with its mounting clamp. Do not do the montage of the device with inappropriate mounting clamp. Be sure that device will not fall while doing the mounting.

It is your responsibility if this equipment is used in a manner not specified in this instruction manual.

1.4 Warranty

Kessler-Ellis Products warrants that the equipment delivered is free from defects in material and workmanship. This warranty is provided for a period of two years. The warranty period starts from the delivery date.

This warranty is in force if duty and responsibilities which are determined in warranty document and instruct on manual performs by the customer completely.

1.5 Maintenance


Repairs should only be performed by trained and specialized personnel. Cut power to the device before accessing internal parts. Do not clean the case with hydrocarbon-based solvents (Petrol, Trichloroethylene etc.). Use of these solvents can reduce the mechanical reliability of the device. Use a cloth dampened in ethyl alcohol or water to clean the external plastic case.

1.6 Other Information


Manufacturer Information:
Kessler-Ellis Products, Inc.
10 Industrial Way East, Eatontown, NJ 07724
USA

Phone: 732-935-1320 • Fax: 732-935-9344
www.KEPmLINE.com


2. General Description



2.1 Front View and Dimensions




2.2 Panel Cut-Out




10 INDUSTRIAL WAY EAST
EATONTOWN, NJ 07724
Office : 800-631-2165 Direct:
732-935-1320
FAX: 732-935-9344

2.3 Panel Mounting



1-Before mounting the device in your panel, make sure that the cut-out of the right size.
2-Insert the device through the cut-out. If the mounting clamps are on the unit, put them before inserting the unit to the panel.
3-Insert the mounting clamps to the fixing sockets that located left and right sides of device and make the unit completely immobile within the panel

2.4 Removing from the Panel



1-Pull mounting clamps from left and right fixing sockets.
2-Pull the unit through the front side of the panel

Before starting to remove the unit from panel, power off the unit and the related system.

3. Using Prokey

TO USE PROKEY, VALUE OF THE PrC PARAMETER MUST BE '0'. IF PrC=1 AND SET BUTTON IS PRESSED, ERR MESSAGE WILL BE SHOWN. 10s. LATER DEVICE TURNS BACK TO THE MAIN OPERATION SCREEN OR YOU CAN PRESS SET BUTTON TO TURN BACK TO MAIN OPERATION SCREEN.

DOWNLOADING FROM DEVICE TO PROKEY

- 1.The device is programmed by using the parameters.
- 2.Energize the device then put in PROKEY and press SET button. ERR Message is shown on the display. When the loading has finished, ERR message is shown.
- 3.Press any button to turn back to main operation screen.
- 4.Remove the PROKEY.


NOTE: ERR message is shown when an error occurs while programming. If you want to reload, put in PROKEY and press SET button. If you want to quit, remove PROKEY and press SET button. The device will turn back to main operation screen.

DOWNLOADING FROM PROKEY TO DEVICE

- 1.Switch off the device.
- 2.Put in PROKEY then energize the device.
- 3.When the device is energized, the parameter values in PROKEY, start downloading to the device automatically. At first, ERR message is shown on the display, when loading has finished, ERR message is shown.
- 4.After 10 seconds device starts to operate with new parameter values.
- 5.Remove the PROKEY.


NOTE: ERR message is shown when an error occurs while programming. If you want to reload, switch off the device and put in PROKEY then energize the device. If you want to quit remove PROKEY and press SET button. The device will turn back to main operation screen.

4. Electrical Wiring Diagram



4.1 Supply Voltage Input Connection of the Device

Power Supply Connection
Make sure that the power supply voltage is the same indicated on the instrument. Switch on the power supply only after that all the electrical connections have been completed. Supply voltage range must be determined in order. While installing the unit, supply voltage range must be controlled and appropriate supply voltage must be applied to the unit.




Note-1 External fuse is recommended.

There is no power supply switch on the device. So a power supply switch must be added to the supply voltage input. Power switch must be two poled for separating phase and neutral, On/Off condition of power supply switch is very important in electrical connection. External fuse that on power supply inputs must be on phase connection. External fuse that on power supply inputs must be on (+) connection.

- P** PID - Proportional Control Parameter (Default = 10.0) MODBUS ADRES:40007 This parameter can be adjusted from %1.0 to %100.0
- I** PID-Integral Parameter (Default = 100) MODBUS ADRES:40008 This parameter value can be adjusted from 0 to 3600.
- d** PID-Derivative Parameter (Default = 25.0) MODBUS ADRES:40009 This parameter value can be adjusted from 0.0 to 999.9
- t** PID-Period parameter (Default = 10) MODBUS ADRES:40010 This parameter value can be adjusted from 0 to 150 second.
- PuL** Operation Scale Minimum Parameter (Default = Minimum Value of Device Scale) MODBUS ADDRESS:40011 This parameter value can be adjusted from minimum value of device scale to operation scale maximum parameter [PuH]
- PuH** Operation Scale Maximum Parameter (Default = Maximum Value of Device Scale) MODBUS ADDRESS:40012 This parameter value can be adjusted from operation scale minimum parameter [PuL] to maximum value of the device scale.
- HSt** Hysteresis Parameter for Compressor Output (Default = 3) MODBUS ADDRESS:40013 from 1 to 20°C for NTC (-50°C, 100°C) or PTC (-50°C, 130°C) or J Type TC (0°C, 800°C) or K Type TC (0°C, 1000°C) or PT-100 Type (-50°C, 400°C) or PT-1000 Type (-50°C, 400°C) or PT-100 Type (-20°C, 100°C), from 1 to 36°F for NTC (-58°F, 212°F) or PTC (-58°F, 266°F) or J Type TC (32°F, 1472°F) or K Type TC (32°F, 1830°F) or PT-100 Type (-58°F, 752°F) or PT-1000 Type (-58°F, 752°F) or PT-100 Type (-4°F, 212°F) from 0.1 to 10.0°C for NTC (-50.0°C, 100.0°C) or PTC (-50.0°C, 130.0°C) or PT-100 (-19.9°C, 99.9°C), from 0.1 to 18.0°F for NTC (-58.0°F, 212.0°F) or PTC (-58.0°F, 266.0°F) or PT-100 (-4.0°F, 212.0°F). In ON/OFF control algorithm, temperature value is tried to keep equal to set value by opening or closing the last control element. ON/OFF controlled system, temperature value oscillates continuously. Temperature value's oscillation period or amplitude around set value changes according to controlled system. For reducing oscillation period of temperature value, a threshold zone is formed below or around set value and this zone is named hysteresis.
- SuL** Minimum Temperature Set Value Parameter (Default = Minimum Value of Device Scale) MODBUS ADDRESS:40014 Temperature set value can not be lower than this value. This parameter value can be adjusted from operation scale minimum parameter [SuL] to maximum temperature set value parameter [SuH]
- SuH** Maximum Temperature Set Value Parameter (Default = Maximum Value of Device Scale) MODBUS ADDRESS:40015 Temperature set value can not be bigger than this value. This parameter value can be adjusted from minimum temperature set value parameter [SuL] to operation scale maximum parameter [SuH]
- oFt** Sensor Offset Parameter (Default = 0) MODBUS ADDRESS:40016 from -20 to 20 °C for NTC (-50°C, 100°C) or PTC (-50°C, 130°C) or J Type TC (0°C, 800°C) or K Type TC (0°C, 1000°C) or PT-100 (-50°C, 400°C) or PT-1000 (-50°C, 150°C) or PT-100 (-20°C, 100°C), from -36 to 36 °F for NTC (-58°F, 212°F) or PTC (-58°F, 266°F) or J Type TC (32°F, 1472°F) or K Type TC (32°F, 1830°F) or PT-100 (-58°F, 752°F) or PT-1000 (-58°F, 752°F) or PT-100 (-4°F, 212°F), from -10.0 to 10.0°C for NTC (-50.0°C, 100.0°C) or PTC (-50.0°C, 130.0°C) or PT-100 (-19.9°C, 99.9°C), from -18.0 to 18.0°F for NTC (-58.0°F, 212.0°F) or PTC (-58.0°F, 266.0°F) or PT-100 (-4.0°F, 212.0°F).

- Pos** Compressor Start Delay at Power On Parameter (Default = 0) MODBUS ADDRESS:40017 When power is first applied to the device, compressor is on when this time delay is expired. It can be adjusted from 0 to 20 minutes.
 - SPd** Compressor Stop-Start Delay Parameter (Default = 0) MODBUS ADRES:40018 When compressor is inactive, this time delay must be expired for activation of the compressor. It can be adjusted from 0 to 20 minutes.
 - Std** Compressor Start-Start Delay Parameter (Default = 0) MODBUS ADRES:40019 This time delay must be expired between two activation of the compressor. It can be adjusted from 0 to 20 minutes.
 - PdF** Sensor Defect Parameter (Default = 0) MODBUS ADRES:40020
 - 0 Compressor is OFF in case of sensor defect.
 - 1 Compressor is ON in case of sensor defect.
 - 2 Compressor operates periodically according to [Pon] and [Pof] Time periods in case of sensor defect.
 - Pon** Compressor is active during this time period in case of probe defect (Default = 0) MODBUS ADRES:40021 If probe defect parameter [PdF] is 2, then this parameter is observed. It can be adjusted from 0 to 99 minutes.
 - Pof** Compressor is inactive during this time period in case of probe defect (Default = 0) MODBUS ADRES:40022 If probe defect parameter [PdF] is 2, then this parameter is observed. It can be adjusted from 0 to 99 minutes.
 - ALS** Temperature Alarm Function Selection Parameter (Default = 1) MODBUS ADDRESS:40023
 - 0 Alarm function is inactive.
 - 1 Process High alarm selected.
 - 2 Process Low alarm selected.
 - 3 Deviation High alarm selected.
 - 4 Deviation Low alarm selected.
 - 5 Deviation Band alarm selected.
 - 6 Deviation Range alarm selected.
 - 7 Deviation Range High alarm selected.
- Note: If this parameter is select 0, [Sd], [ALH], [SuL], [SuH], [Pon], [Pof] and [Pd] parameters will be not observed
- RSt** Temperature Alarm Set Parameter (Default = 80) MODBUS ADDRESS:40024 This parameter value can be programmed between temperature minimum alarm set [SuL] parameter and temperature alarm set maximum [SuH] parameter.
 - ALH** Temperature Alarm Hysteresis Parameter (Default = 3) MODBUS ADDRESS:40025 This parameter value can be adjusted from 0.1 to %50 of the device scale if Pnt parameter is 1, 1 to %50 of the device scale if Pnt parameter is 0.
 - RuL** Temperature Minimum Alarm Parameter (Default = Minimum Value of Device Scale) MODBUS ADDRESS:40026 If temperature alarm is active, this parameter value can be adjusted from operation scale minimum parameter [SuL] to temperature alarm set maximum parameter value [SuH].
 - RuH** Temperature Alarm Maximum Parameter (Default = Maximum Value of Device Scale) MODBUS ADDRESS:40027 If temperature alarm is active, this parameter value can be adjusted from temperature alarm set value parameter [RuL] to operation scale maximum parameter [SuH].
 - Ron** Temperature Alarm On Delay Time Parameter (Default = 0) MODBUS ADDRESS:40028 Temperature alarm on delay time can be defined with this parameter. It can be adjusted from 0 to 99 minutes.

5. Front Panel Definition and Accessing to the Menus




BUTTON DEFINITIONS

- 1. Increment Button :** ** It is used to increase the value in the Set screen and Programming mode.
- 2. Decrement, Silencing Buzzer and Downloading to Prokey Button :** ** It is used to decrease the value in the Set screen and Programming mode. ** It is used to silence the buzzer. ** If PrC = 0, it is used to download from device to prokey.
- 3. Set Button :** ** In the main operation screen; if this button pressed, temperature set value will be displayed. Value can be changed using increment and decrement buttons. When Enter button pressed, value is saved and alarm set value is displayed. Value can be changed using increment and decrement buttons. When Enter button pressed, alarm set value is saved and returns back to main operation screen. ** To access the programming screen; in the main operation screen, press this button for 5 seconds.
- 4. Enter Button :** ** It is used to saving value in the Set screen and programming screen. ** In the main operation screen; press ENTER button for 3 seconds to start Auto Tune operation.


LED DEFINITIONS

- 5. Cooling led :** ** This led indicates that cooling control is selected and process output relay is active. If any of compressor protection time active, this led blinks.
- 6. Heating led :** ** This led indicates that heating control is selected and process output relay is active.
- 7. Alarm led :** ** This led indicates that alarm output relay is active.
- 8. Celcius led :** ** This led indicates that device is in °C mode.
- 9. Fahrenheit led :** ** Indicates that device is in °F mode.
- 10. Auto Tune / Self Tune led :** ** Indicates that device is operating Auto Tune or Self Tune.
- 11. Set led :** ** Indicates that device is in Set value changing mode.
- 12. Program led :** ** Blinks in programming mode.

6. Changing and Saving Temperature Set Value And alarm Set Value



When SET button pressed "S" led will be active and temperature set value will be displayed. Temperature set value can be changed with increment and decrement buttons.



When ENTER button pressed alarm set value can be saved. "S" will be inactive and goes back to main operation screen.

Temperature set value parameter (Default=50) MODBUS ADDRESS:40001 Temperature set value, can be programmed between minimum temperature set value [SuL] and maximum temperature set value [SuH].

6.1 Programming Mode Parameter List

- C-F** Temperature Unit Selection Parameter (Default = 0) MODBUS ADDRESS:40002
 - 0 °C selected.
 - 1 °F selected.
- Pnt** Decimal Separator Enabling Parameter (Default = 0) MODBUS ADDRESS:40003
 - 0 Disable.
 - 1 Enable.

Note: If sensor input type is selected J, K, PT-100 or PT-1000 (BC = 05, 10, 11 or 14) [Pnt] parameter is skipped.

HCS Operating Type Parameter (Default = 0) MODBUS ADDRESS:40004

- 0 Heating
- 1 Cooling

Note: If operating type is selected cooling [P-o] parameter and PID parameters are skipped. Device operates with On-Off control.

P-o Temperature Control Selection Parameter On/Off or PID (Default = 0) MODBUS ADRES:40005

- 0 On - Off selected.
- 1 PID selected.

Note: If this parameter is select 0, PID parameters will be not observed. If this parameter select 1, HSt Parameter will be not observed.

tun Tune Selection Parameter (Default = no) MODBUS ADRES:40006

- 0 Device does not do Tune operation.
- 1 Device does Auto-Tune operation
- 2 Device does Self-Tune operation

Note-1: If this parameter is select [tun] the temperature must be lower than temperature set value. If this condition is not okay [Err] is seen on the main screen for 10 seconds.
Note-2: If this parameter is select [tun] the temperature must be greater than temperature set value at least 5% of the full scale. If this condition is not okay [Err] is seen on the main screen for 10 seconds.

- Rof** Temperature Alarm Off Delay Time Parameter (Default = 0) MODBUS ADDRESS:40029 Temperature alarm off delay time can be defined with this parameter. It can be adjusted from 0 to 99 minutes. If it is higher than 99 [Err] is seen on the screen and alarm latching output is selected. In alarm latching output mode, in order to make passive alarm output, press DECREMENT button at main screen.
- APd** Temperature Alarm Delay After Power On Parameter (Default = 0) MODBUS ADRES:40030 When power is first applied to the device, this time delay must be expired for activation of temperature alarm. It can be adjusted from 0 to 99 minutes.
- buzF** Buzzer Function Selection Parameter (Default = 0) MODBUS ADDRESS:40031
 - 0 Buzzer is inactive.
 - 1 Buzzer is active during sensor failures.
 - 2 Buzzer is active if an alarm occurs.
 - 3 Buzzer is active if an alarm occurs or sensor failures.
- bon** Buzzer is active during this time (Default = -) MODBUS ADDRESS:40032 If buzzer function selection parameter value [buzF] = 0, this parameter can not be observed. Buzzer stays active during this time. It can be adjusted from 1 to 99 minutes. When this parameter is 1, if decrement button is pressed, [Err] is observed. In this condition buzzer is active till buzzer silence button is pressed.
- ids** Increment/Decrement Mode Selection Parameter (Default = 0) MODBUS:40033
 - 0 Mode-1
 - 1 Mode-2
- PrC** Communication Mode Selection Parameter (Default = 0) MODBUS ADDRESS:40034
 - 0 PROKEY communication selected.
 - 1 Rs485 communication selected.
- SAd** Slave ID Parameter (Default = 1) MODBUS ADDRESS=40035 Device communication address parameter (1 to 247).
- PAS** Programming Section Accessing Password (Default = 0) MODBUS ADDRESS:40036 It is used for accessing to the programming section. It can be adjusted from 0 to 9999. If it is selected 0, password will not be asked.

Note: [Pos], [SPd], [Std], [PdF], [Pon] and [Pof] Parameters are observed if Operation type is selected "Cooling". If operation type is selected "Heating", skip to the [buzF] parameter.


6.2 Modbus Addresses of Device Status Parameters (Read Input Register)

- MODBUS ADDRESS:30001** Temperature Value
- MODBUS ADDRESS:30002** Empty
- MODBUS ADDRESS:30003** Led Status : 0.bit °C Led, 1.bit °F Led, 3.bit "Auto Tune Led, 5.bit Heating Led, 6.bit Compressor Led, 7.bit Alarm Led, 13.bit Program Led, 14.bit Set Led
- MODBUS ADDRESS:30004** Device Status : 0.bit Alarm Status 1.bit Buzzer Status 2.bit Sensor Break Status
- MODBUS ADDRESS:30005** Output Status : 0.bit Control Output 1.bit Alarm Output
- MODBUS ADDRESS:30006** Device Type and Device Version

6.3 Failure Messages


[Err] Screen Blinking
Sensor failure. Sensor connection is wrong or there is no sensor connection. If buzzer function selection parameter [buzF] is 1, internal buzzer starts to operate.

6.4 Entering To The Programming Mode, Changing and Saving Parameter




When SET button is pressed for 5 seconds, "P" led starts to blink. If programming mode entering password is 0, [Err] Temperature Unit screen is observed instead of programming screen [PrC] will be observed.

Note1: If programming mode accessing password is 0, [Err] Temperature Unit screen is observed instead of programming screen [PrC] will be observed.




Enter programming mode accessing password with increment and decrement buttons. Press OK button for entering the password.

Note2: If programming mode accessing password is 0, only three parameters are accessible, and the parameter values can be changed.



Press SET button for accessing to the parameter value. Press increment button for accessing to the next parameter, press decrement button for accessing to the previous parameter.



Press OK button for saving the parameter. Press increment button for accessing to the next parameter, press decrement button for accessing to the previous parameter

Note: If no operation is performed in programming mode for 20 seconds, device turns to main operation screen automatically.